

## SCREW COMPRESSOR \$75E - 42 Refrigerating capacity and power consumption Volume ratio 4.2 STALOMIZER

## **CAPACITY AND POWER CONSUMPTION**

The capacity curves refer to a process with subcooling of the liquid to the intermediate temperature (Stalomizer-temperature) and with no superheating of the suction gas. Correction for STALOMIZER-system with heat exchanger and correction for superheating are to be made according to manual sheet 411-E-10. Check another built-in volume ratio for best efficiency. Capacity (60 Hz) = Capacity (50 Hz) $\times$ 1.2 Compressor input (60 Hz) = Compressor input (50 Hz) $\times$ 1.2 t<sub>1</sub> = condensing temperature

For intermediate temperatures see manual sheet 4840-E-5E.

### **CONDENSER PERFORMANCE**


For condenser performance see manual sheet 4840-E-1.

### **LIMITATIONS**

There are certain limitations in the operation range of the compressor.

For combination of condensing and evaporating temperatures outside the curves, ask for further information.

50 Hz 2950 r/m Refrigerant: NH<sub>3</sub>
Cooled oil



Evaporating temperature (C)

# SCREW COMPRESSOR S75E – 42 Refrigerating capacity and power consumption Volume ratio 4.2 STALOMIZER

Refrigerant: NH<sub>3</sub>
Cooled oil

50 Hz 2950 r/m

